


### String

Adjust OSC A and OSC B FREQ knobs to match the frequency of the string you wish to imitate. Adjust OSC A and OSC B FREQ knobs to match the frequency of the string you wish to imitate. Adjust OSC A and OSC B FREQ knobs to match the frequency of the string you wish to imitate.




### Percussive Organ

Tune OSC A 2 octaves plus a perfect fifth above OSC B. For proper effect, adjust OSC A PULSE WIDTH for square wave by listening for disappearance of the octave overtone. FILTER ENVELOPE AMOUNT adjusts brightness of percussive effect. Mod-wheel provides vibrato.








### "Delayed" Envelope

Uses LFO as an envelope generator. (LFO is reset by keyboard trigger when ARPEGGIATE is switched on.)



### Bass Synth Sustain

Tune OSC A 1 octave below OSC B.













